

CONCRETE TEST HAMMER (BIG)

MODEL NO SL -CC -101, MAKE - LABTEK, ORIGIN - INDIA



It is similar to the above but is used for testing concrete with over size aggregates (for which test, cubes promise no reliable results) and for testing concrete roads. Its plunger is wider as such, the amount of concrete reached by the impact is considerably greater. With this model also the results obtained are within 20% of the actual compressive strength. The instrument is supplied with two handles which can be attached to the body of the concrete test hammer for carrying out the test easily. Complete with grinding stones.