

FLOW TABLE

MODEL NO – SL-CC-068, MAKE – LABTEK, ORIGIN – INDIA



IS : 6932 (PART VIII) ASTM C 230,BS 4551:1

This is used for determining the work ability of building limes.

Specification:

The flow table consists of a 30 cm dia. polish steel plate with 3 engraved annular circles 7, 11 and 19cm dia. The table top is arranged for a free fall of 12.5mm by a cam action. Supplied complete with one brass conical mould, 65mm i.d. at base and 40mm i.d. at top, height of the mould 90mm.