

VE BEE CONSISTOMETER

MODEL NO – SL-CC-073, MAKE – LABTEK, ORIGIN – INDIA



IS 1199 & BS EN 12350.

The instrument is used for work ability as well as consistency of fresh concrete. A slump Cone and a graduated rod supplied with the instrument helps the operator to find out slump values and vibration table with container and acrylic disc is used to find out work ability of concrete expressed in Vee Bee degrees, which is defined as the time in seconds to complete required vibrating at which the fresh concrete flows out sufficiently to come in contact of the entire face of acrylic disc.